

	E1200	E1300	E1800	E1900	E2000	E2100
S 4700						
		A II A III				
S 5000			A			
S 5500				A		
S 6000			A			
S 6500					A	

Dato	Konstr./Tegnet	Godkjent	Målestokk
9-88	L.NESSVOLL		1:4000
BORHULLS LOKALISERING S4600-6500 E 600-2100			10/10
Henvisning:		Beregning:	